



**DETAIL A**

NOTES:

- 1. SOLDER WHITE/BLUE WIRE TO CCW TERMINAL, WHITE/ORANGE WIRE TO CW TERMINAL, WHITE WIRE TO RW TERMINAL.
- 2. USE HEAT SHRINK TUBING ON ALL SOLDER CONNECTIONS.
- 3. COUNTERSINK AND RIVET AS SHOWN.

