



NOTES:

- 1. SP71403-001 MUST BE MOUNTED CENTERED ON AND PARALLEL TO AIRCRAFT BUTTLINE.
- 2. MATCH DRILL 3X Ø.219 HOLES THROUGH SC26002-001
- 3. LOCATE AND DRILL Ø.625 HOLE THROUGH SC26002-001.
- 4. ALL PIECES OF RM5401-001 MUST CONTACT DOUBLER PLATE OF SP71403-001
- 5. PART OF SP71403-001
- 6. MASK STEEL WHIP OF SP71403-001 PRIOR TO PAINTING.
- 7. REMOVE STICKER FROM BASE OF SP71403-001 AND PREPARE SURFACE OF BASE PER CCPS005 PRIOR TO PAINTING.

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
3	RM5401-001	VAPOR BARRIER TAPE, 2" ALUMINUM	AR
2	SP71403-001	ANTENNTA, VHF, COM (AV-530)	1
1	SC26002-001	TURTLE DECK	1

TURTLE DECK ANTENNA ASSEMBLY